


REF. NO.	ITEM NO.	DESCRIPTION	MODELS	
			38J	39J
1	10029	Motor Base and Nose Cone Housing	1	
1A	10031	Motor Base and Nose Cone Housing		1
2	27008	Rubber Flap 30"		
2A	27009	Rubber Flap 36"	1	
3	27006	Rubber Flap Holder 30"		1
3A	27007	Rubber Flap Holder 36"	1	
4	33014	4" Castor Wheel Assembly		1
5	31038	3/4" Thumb Nut for Castor Wheel	2	2
6	36000	Flange for 1" Bearing	2	2
7	36001	1" Bearing with lock flange and Set Screw	4	4
8	36002	Main Brush Shaft 30"	2	2
8A	36003	Main Brush Shaft 36"	1	
9	31039	1/4" Woodruff Key		1
10	36004	1" Sprocket for #35 Chain	1	1
11	27010	30" Brush	1	1
11A	27011	36" Brush	1	
12	27012	30" Brush Holder		1
12A	27013	36" Brush Holder	1	
13	36005	Chain #35		3
15	36006	Belt Pulley and Sprocket	1	1
16	31037	3/16" Key Way	1	1
17	31040	5/16" Set Screw	1	1
18	36007	Pulley 3/4 x 1 3/4"	1	1
19	31041	5/8" Brass Washers	1	1
20	36008	5/8" Pulley Cam	2	2
21	31042	5/8" Oil Seal	1	1
22	36009	Roller Bearing 5/8"	2	2
23	31043	1/2" Flat Washer	2	2
24	31034	3/8" Flat Washer	1	1
26	31033	Bolt 3/8" x 1"	1	1
27	31034	3/8" Flat Washer	1	1
28	31033	Bolt 3/8" x 1"	1	1
29	31006	Bolt 5/16" x 1 1/2"	2	2
30	31003	5/16" Lockwasher	4	4
31	31027	5/16" Flat Washers	14	14
32	31004	5/16" Nuts	2	2
33	36011	Belt	16	16
34	31044	1/4 x 1" Bolt Hex Head	1	1
35	31013	1/4" Lockwasher	20	20
36	31030	1/4" Nut	24	24
37	27004	Belt Guard	24	24
37A	27005	Belt Guard	1	
38	31045	Bolt 3/8" x 3 1/2" Hex Head		1
39	31009	3/8" Nut	2	2
40	31032	5/16" x 1" Bolt Hex Head	2	2
41	31046	5/16" x 3/4" Carriage Bolt	3	3
42	31047	Roll Pin	6	6
43	31073	Pillow Blocks	2	2
44	31048	1/2" x 5 1/2" Pin	2	2
	35000	Throttle Control	1	1
45	33004	Caster Wheel 3"	1	1
46	33015	Front Lifter and Axle Support	2	2
46A	33016	Front Lifter and Axle Support	1	
47	31049	3/4" Collar		1
48	31040	5/16" Set Screw	1	1
			1	1

Continued next page.

PARTS LIST NO. 5704

<u>REF. NO.</u>	<u>PARTS NO.</u>	<u>DESCRIPTION</u>	<u>38J</u>	<u>39J</u>
49	31050	1/4" x 2" Bolt Hex Head	4	4
50	23033	Lifter Arm	1	1
51	31031	Bolt 5/16" x 3/4" Hex Head	2	2
52	23024	Lower Lifter Handle	1	
52A	23024	Lower Lifter Handle		1
53	23023	Upper Lifter Handle	1	
53A	23025	Upper Lifter Handle		1
54	31104	Rubber Handle	1	1
	39000	3 H.P. B&S Engine		



MODELS 38J - 39J
 ROTARY BRUSH ATTACHMENT